


SOFTWARE SETUP

HOME




Download and launch the **FREE** app using iTunes.®

The main ride screen includes display for cycling data captured, including speed, cadence, distance traveled, and elapsed time.

Slide the green chainlink icon to the left or right to access menu options and set up your ride information.

Select the green chainlink icon at any time to return to the ride screen.

MENU




The menu screen provides access to new ride setup, saved ride data, ride map, and settings information.

"Saved Rides" will display time, average speed, cadence, distance, max speed, and calories for each session in graph form. "Saved Rides" will allow you to make ride notes and export all data captured via email.

Select "Settings" to enter your bike information.


SETTINGS



Settings options allow you to add your bike information, manage your bike information, turn your device's auto lock on or off, select your average mode, and access in-app help.

Average mode allows you to control the detail displayed in the average speed and cadence graph.

INFO & HELP



Select "Help" in your settings options to view app version information, email LiveRider support, or view an in-app overview of LiveRider hardware setup.

Select "Current Bike Settings" in your settings options to add custom bike and ride information.

CURRENT BIKE SETTINGS



Choose your bike name, and enter it in the "Name" field. Select your wheel size from the included list.

Your LiveRider cycle sensor will automatically pair with the LiveRider receiver; verify this by rotating your bike wheel.

Select your units (Miles/MPH or Kilometers/KPH). Estimate and enter your riding weight, which includes the weight of your body, bike, and gear.

Select the chain link icon to save and return to the ride screen.

Press "Start" to begin a new bike ride.

STARTING YOUR BIKE RIDE



When your hardware and software setup is complete and you begin bike riding with LiveRider, the green light on the receiver should blink about once a second. This indicates that the LiveRider cycling receiver is receiving information from the sensor. As pictured here, the green chainstay icon on the main screen will say "Start" or "Resume" when the app is successfully communicating with the receiver.